

Multifunctional Power Bank

User Manual

and **COLORS**

www.andcolors.com/powerbank

Product Features

Thank you for purchasing the andCOLORS power bank. To have the best experience with your andCOLORS power bank and to insure proper understanding of the functionality and safe operation, please read the user manual carefully.









The power bank can be used with mobile phones and other digital devices that require charging by DC5V.

A wide range of applications

The andCOLORS power bank can be used to provide and maintain power for digital products such as iPhones, MP3/MP4 players, PSP, mobile phones, Bluetooth devices, and tablets.

Product safety


The Polymer Lithium Ion battery core features intelligent circuit protection designed for maximum safety and security.

 Over-charging protection Circuit protection prevents battery overcharging	 Over-discharge protection Prevents battery from over-discharging current
 Overvoltage protection Prevents overvoltage when charging	 Over current protection Prevents too much current going into power bank and out to the connected device
 Short circuit protection Automatic protection in the event of a short circuit	 High-temperature protection High-temperature protection insures battery operates at a safe range
 Over power/discharge protection Circuitry prevents over power and excessive battery discharge	 EMF protection Built-in protection against electromagnetic fields so that they do not affect the operation of the power bank

Instruction

When using the power bank to charge other devices

This product has Lightning and microUSB outputs. You can use the appropriate output according to your charging needs.



Attention

1. Do not use the power bank in high temperature or humid environments, or under direct exposure from the sun. (Operating temperature range - Charging: 0-45°C, Discharge: 10-60°C, Storage temperature range: -20-60°C)
2. To prevent the possibility of fire or explosion, never expose the power bank to open flames or water.
3. Please store this product in locations outside the reach of children.
4. Never attempt to repair or disassemble this product by your self. There are no internal parts that can be extracted or reused.
5. Please do not drop, strike or expose the product to excessive vibration.
6. Stop using the product immediately if any abnormal activity is noticed such as leakage or bulging of the case. Please contact an authorized customer service center for help.
7. If your eyes are accidentally exposed to any fluid leaked from the device, please wash with clean water and seek immediate medical attention.
8. During normal operation, the temperature of the power bank will increase. Please take precaution when in use or storing the product.
9. Never allow children to use the product without adult's supervision.
10. Before using the power bank with your product, please check the voltage requirements to insure that it will not damage your device.
11. To avoid possible damage or property loss, please insure the device is not in use before unplugging from the input power source or outlet.

www.andcolors.com/powerbank